

# Fast (Deep) Capture of IQ Vector Waveform Data from X-Series Signal Analyzers using MATLAB®

---

**Revision Date: April 16, 2013**

## **Overview**

This lab example utility program demonstrates how to capture up to 2GB (512 Mega Samples) of I/Q waveform data from an X-Series Signal Analyzer. Software revision A.11.02 or later is required, since the Fast Capture (FCAP) command to extract the full 2 GB of data from the IQ Analyzer mode was added in A.11.02 software. Previously, the FCAP command was only included in the VXA measurement application. Option DP2 (or B1X, or B1Y or B40 or MPB) is required to enable the 2 GB memory capture in X-Series Analyzers. This example can either be run using MATLAB running inside an X-Series Analyzer or MATLAB running on an external PC and connected to the Analyzer via LAN, USB or GPIB. This example uses VISA instrument control libraries. For simplicity, the steps to run this example program demonstrate VISA using the Agilent IO Suite libraries.

Equipment Required for this Example Program:



- a) Agilent X-Series Signal Analyzer (PXA, MXA, EXA) with at least one of the following options: DP2, B40, B1X, B1Y, or MPB
- b) MATLAB 2010a or later installed on PC or on X-Series Analyzer
- c) If Using external PC, a LAN, USB or GPIB cable are needed to connect the PC to the X-Series Analyzer
- d) Agilent IO Suite version 14.0 or later

## Step 1 – Connect Analyzer to LAN (if MATLAB is on an external PC)


- a. To find the IP address of the Signal Analyzer, press [System] <Show> <LXI>  
PXA/EXA/MXA IP Address: \_\_\_\_\_

## Step 3 – Open MATLAB

- a. Open MATLAB and Restore the Default Desktop Layout



- b. Navigate to the folder containing this lab
- c. Double-click on deepCapture.m to be able to view the code for this example function



## Step 4 – Double Check that you can communicate to your instruments

From the Command Window in MATLAB type you can test to make sure your instrument can be reached via LAN by using the Ping utility provided with Windows. To execute system commands from the MATLAB prompt, one can use the bang(!) operator.

At the MATLAB prompt type: !Ping <I.P. Address> and press Enter.

```
Command Window
>> !ping 141.121.92.208


Pinging 141.121.92.208 with 32 bytes of data:

Reply from 141.121.92.208: bytes=32 time=24ms TTL=128
Reply from 141.121.92.208: bytes=32 time<1ms TTL=128
Reply from 141.121.92.208: bytes=32 time<1ms TTL=128
Reply from 141.121.92.208: bytes=32 time<1ms TTL=128


Ping statistics for 141.121.92.208:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
```

## Step 5 – Double Check that your version of MATLAB has the Instrument Control Toolbox

- a. In MATLAB 2012b and later, the Instrument Control Toolbox is under the Apps tab:



- b. In prior versions of MATLAB, click on the Start button in the lower left corner of the MATLAB window and scroll up to Toolboxes. You should see the Toolbox “Instrument Control” listed.



## Step 6 – Discover the available hardware to MATLAB on your PC

Type “instrhwinfo” from the Command Window

```

Command Window
>> instrhwinfo

ans =

    MATLABVersion: '7.10 (R2010a)'
SupportedInterfaces: {'gpib' 'serial' 'tcpip' 'udp' 'visa'}
SupportedDrivers: {'matlab' 'ivi' 'vxipnp'}
ToolboxName: 'Instrument Control Toolbox'
ToolboxVersion: '2.10 (R2010a)'

```

```



Command Window
>> instrhwinfo

ans =

    MATLABVersion: '8.1 (R2013a)'
SupportedInterfaces: {1x7 cell}
SupportedDrivers: {'matlab'}
ToolboxName: 'Instrument Control Toolbox'
ToolboxVersion: '3.3 (R2013a)'

```


## Step 7 – Map Instruments in Agilent IO Libraries Suite

- a. Open the Agilent Connection Expert either by double clicking the IO button  or  in your PC's task tray at the bottom right of the screen,


or by right click on the IO button and clicking “Agilent Connection Expert”



or by going to Start -> All Programs -> Agilent IO Libraries Suite -> Agilent Connection Expert





Or by going to Start -> All Program -> Agilent Connection Expert



- b. Add your X-Series Analyzer to the list of LAN instruments configured in Agilent Connection Expert. Click LAN and then click Add Instrument and then Add Address.


Make sure when adding a LAN instrument that the “Add to configuration” check box is checked.

(Note: if you are running MATLAB installed on the instrument, then you do not need to do this. The instrument is already listed as a LAN instrument using the local host address of 127.0.0.1




## Step 8 – Start Evaluating/Executing the Code in the Program.


- You can execute MATLAB scripts using one of the many possible ways. Typing in the name of the script, or right-clicking on the script in your MATLAB current directory browser and selecting "Run" will execute the commands in the script.
- Click on DeepCaptureGUI.m and press F9 to run



- When the Deep Capture GUI appears press "Perform Deep Capture"



- The command window will show you how long it took to perform the capture



- You can also save the captured data to a .MAT file, and you can change the bandwidth and time.  
Note: You usually would not change the Block transfer size, unless you were trying to optimize transfer speed time.